SUNGROW
Clean power for all

Quick Installation Guide


1-Phase Hybrid Inverter


MG5RL/ MG6RL




MG5RL/MG6RL-QIMUL-Ver11-202504

Scope of Delivery



Inverter



Wall-mounting bracket



Battery Connector


AC Connector(x 3)



Expansion Plug Set(x 3)


M5×12 Screw Set(x 2)


M4×16 Screw Set(x 4)



Current Transformer(CT)



DO Plug-in Connector


Signal Plug-in Connector


Wire Ferrule(×9)


Wire Ferrule (DIN end) (×12)


PV Connector(×2 set)


Crimp contact(×2 set)


Removal tool


Desiccant


Documents



WiNet-S2(optional)**


* The images shown here are for reference. The actual product and quantity are based on delivery.


**WiNet-S2 is not included as standard but is available for seperate purchase.


Mounting location



































For more information about mounting location, please contact SUNGROW.

Installation tools







Mounting



Terminal Description




PE Connection





The cable specification must comply with local regulations (if available). Otherwise, keep it consistent with the PE wire in the AC cable.


AC Cable Connection





DC Cable Connection


































Backup Connection






















GEN Connection


















Battery Connection

Battery DC Breaker

Recommended DC Breaker
V＞Maximum battery voltage
I Recommended： 150A



*When the battery has no switch, a DC breaker should be added.

Battery Cable


MG5RL:35 mm²
MG6RL:50 mm²




A: E+(2~3) mm



1




2




(1) 9-13 mm
(×2) (2)12-16 mm


3




4




5




6






⚠The positive and negative terminals on the battery side must not be reversed.

7




8




WiNet-S2


Installation with WLAN communication



Ethernet




COM2 Terminal Communication Connection





Label	Description
DO(NO/1, COM/2)	For ground fault alarm, intelligent load control or genset control.
Parallel_1	For parallel RS485 communication (IN)
Parallel_2	For parallel RS485 communication (OUT)
DRM(3V3, DRM0)	DRM0 is only for AU， others are reserved.
RSD(RSD_1, RSD_2)	Reserved (Detail availability contact SUNGROW)
BAT_TEM(PT-, PT+)	Reserved (Detail availability contact SUNGROW)
METER(A2,B2)	For smart energy meter
CT	For grid CT signal sampling
BMS-485/CAN	Only 4/H and 5/L are used for battery communication via CAN protocol, others are reserved.


CT Connection


* The length of CT cable is 5m.

















Smart Energy Meter Connection







If the communication distance (L) ≤ 10m, use a RS485 communication cable for connection directly.
If L ＞ 10m, add an extra 120Ω resistor to improve the communication quality.



DO Connection(For GEN Communication)




Battery Communication




*Before connecting the communication cable, ensure the wire sequence is consistent.

Power on



- Wait 5 minutes after completing the previous step before proceeding to the next one.



LED indicator

LED indicator	LED state	Definition
	ON	The inverter is running in the on/off-grid mode.
	Twinkling	The inverter is at standby or startup state (without on/off-grid operation). The inverter is recovering from a fault.
	ON	A system fault has occurred.
	OFF	Both the AC and DC sides are powered down.

Battery SOC Indicator

Battery SOC Indicator	SOC
	0
	0<SOC≤20%
	20%<SOC≤40%
	40%<SOC≤60%
	60%<SOC≤80%
	SOC＞80%

EN

1. Contents may be periodically updated or revised due to product development. The information in this guide is subject to change without notice. In no case shall this guide substitute for the user manual or related notes on the device.
2. Make sure to read over, fully understand and strictly follow the detailed instructions of the user manual and other related regulations before installing the equipment. The user manual can be downloaded by visiting the website at http://support.sungrowpower.com/; or it can be obtained by scanning the QR code on the side of the equipment or the back cover of this guide.
3. All operations can be performed only by qualified personnel, that must be trained for installation and commissioning of electrical system, as well as dealing with hazards, have knowledge of the manual and of the local regulations and directives.
4. Before installation, check that the package contents are intact and complete compared to the packing list. Contact SUNGROW or the distributor in case of any damaged or missing components.
5. The cable used must be intact and well insulated. Operation personnel must wear proper personal protective equipment (PPE) all the time.
6. Any violation could result in personal death or injury or device damage, and will void the warranty.

Safety

The inverter has been designed and tested strictly according to international safety regulations. Read all safety instructions carefully prior to any work and observe them at all times when working on or with the inverter. Incorrect operation or work may cause:

- injury or death to the operator or a third party;
- damage to the inverter or other properties.

Please follow the safety instructions related to the PV strings and the utility grid.

⚠ DANGER

Lethal voltage!

- PV strings will produce electrical power when exposed to sunlight and can cause a lethal voltage and an electric shock.
- Only qualified personnel can perform the wiring of the PV panels.

⚠ NOTICE

Danger to life from electric shock due to lethal voltage!

- All electrical connections must be in accordance with local and national standards.
- Only with the permission of the local utility grid company, the inverter can be connected to the utility grid.

Inverter

The warning label on the inverter body are as follows.

	Disconnect the inverter from all the external power sources before maintenance!
	Do not touch live parts for 10 minutes after disconnection from the power sources.
	Burn danger due to hot surface that may exceed 60 °C.

	Danger to life due to high voltages! Only qualified personnel can open and maintain the inverter.
	Read the user manual before maintenance!
	The inverter does not have a transformer.
	TÜVRheinland mark of conformity.
	TÜV mark of conformity.
	CE mark of conformity. EU/EEA Importer.
	Do not dispose of the inverter together with household waste.
	Additional grounding point.

Users may also attach other warning signs as per the requirements of the local standards or installation specifications.

⚠ DANGER

Danger to life from electric shocks due to live voltage

- Do not open the enclosure at any time. Unauthorized opening will void warranty and warranty claims and in most cases terminate the operating license.
- When the enclosure lid is removed, live components can be touched which can result in death or serious injury due to electric shock.

Lethal danger from electric shock due to possibly damaged inverter

- Only operate the inverter when it is technically faultless and in a safe state.
- Operating a damaged inverter can lead to hazardous situations that can result in death or serious injuries due to electric shock.

⚠ WARNING

Risk of inverter damage or personal injury

- Do not pull out the PV connectors and AC connector when the inverter is running. Disconnect the AC circuit breaker and set the DC load-break switch of the inverter to OFF. Wait 10 minutes for the internal capacitors to discharge. Verify that there is no voltage or current before pulling any connector.

⚠ WARNING

All the warning labels and nameplate on the inverter body:

- must be clearly visible; and
- must not be removed, covered or pasted.

⚠ CAUTION

Risk of burns due to hot components!

- Do not touch any hot parts (such as the heat sink) during operation. Only the DC switch can safely be touched at any time.

⚠ NOTICE

Only qualified personnel can perform the country setting. Unauthorized alteration may cause:

- A breach of the type-certificate marking.

Risk of inverter damage due to electrostatic discharge (ESD)!

By touching the electronic components, you may damage the inverter. For inverter handling, be sure to:

- avoid any unnecessary touching; and
- wear a grounding wristband before touching any connectors.

Battery

⚠ DANGER

Batteries deliver electrical power, resulting in burns or a fire hazard when they are short circuited, or wrongly installed.

Lethal voltages are present in the battery terminals and cables in the inverter. Severe injuries or death may occur if the cables and terminals in the inverter are touched.

⚠ NOTICE

Improper settings or maintenance can permanently damage the battery.

Incorrect inverter parameters will lead to the premature aging of battery.

EU Declaration of Conformity

within the scope of the EU directives

The object of the declaration described above is in conformity with the relevant Union harmonisation legislation:

Low Voltage Directive 2014/35/EU (LVD)

Electromagnetic compatibility 2014/30/EU（EMC)

Restriction of the use of certain hazardous substances 2011/65/EU and 2015/863/EU (RoHS)

The manufacturer Sungrow Power Supply Co. Ltd, China hereby confirms that the product MG5RL, MG6RL complies with the essential requirements and other relevant provisions of Directive 2014/35/EU (LVD), 2014/30/EU (EMC),2011/65/EU and 2015/863/EU (RoHS).

The communication module that comes with the inverter and the technical parameters of wireless communication are listed in the table below. The model of the communication module actually delivered shall prevail. The EU Declaration of Conformity for the communication module can be found at support.sungrowpower.com.

WiNet-S/WiNet-S2:

Radio technology	WLAN 802.11b/g/n20/n40	
Radio spectrum	802.11b/g/n20	2412 MHz ~ 2472 MHz
	802.11n40	2422 MHz ~ 2462 MHz
Maximum transmission power	≤ 20 dBm	

Technical parameters listed above apply to EU countries only.

Manufacturer : Sungrow Power Supply Co., Ltd.
No 1699. Xiyou Road,Hefei 230088.P.R.China
For EU only
EU/EEA Importer: Sungrow Deutschland GmbH
Balanstraße 59, 81541 München, Germany

Security Declaration

For details on the product's network security vulnerability response process and vulnerability disclosure, please visit the following website:
https://en.sungrowpower.com/security-vulnerability-management

For more information on network security, please refer to the user manual of the communication module or the Data Logger that comes with the product.

More information in the QR code or
at http://support.sungrowpower.com/

SUNGROW

Sungrow Power Supply Co., Ltd.

www.sungrowpower.com

M0H0130000-6

QIMUL M0H01300